




**INSTRUCTION MANUAL FOR MODELS:
LA06/LA07/LA10/GT10/GT14**



- S1. Start/stop button
- S2. Lap/reset button
- S3. Mode button
- S4. Light button

FEATURES

- Time Of Day
- 1/100s Stopwatch up to 1 hour
- Dual Time
- Daily Alarm
- Dual Time Alarm
- Preset Timer (1, 3, 5, 10, 15, 20, 25, 30, 45 and 60 minutes)
- Hourly Chime
- Calendar (Month/Date/Day of Week)
- 3 seconds delay EL backlight
- 50M water resistant
- 10 lap and lap recall function
- Easy setting function

DISPLAY MODES

The watch has five display modes: HOME TIME (TIME) / FOREIGN TIME (TM-2), ALARM (ALM1/ALM2), STOPWATCH (STW), COUNTDOWN RECALL DATA (RCL) and TIMER (TMR).

To change from one display mode to another, press S3 button once. The mode description will appear for approximately 2 seconds before activating the selected mode.

PROMPTING ARROWS

The S1, S2 and S3 buttons each has a prompting arrow.

Their corresponding arrow will appear whenever the button is required while setting the times, calendar and alarms.

In any setting mode, holding S1 button for approximately 2 seconds will advance the digits at a fast pace.

HOME AND FOREIGN DISPLAY

To display FOREIGN TIME, press S2 button when HOME TIME is displayed. The mode description (TM-2) will appear shortly before FOREIGN TIME is displayed. To change back to HOME TIME, press S3 button again.

TIME

TO SET THE TIME AND CALENDAR

1. Press S3 button to select time mode.
2. Press S2 button to toggle between HOME TIME and FOREIGN TIME mode.
3. Press and hold S2 button for 2 seconds until the message "SET" appears and the hour digits blink.
4. Press S1 button once to increase the digits by one unit, holding down the button will speed up the process.
5. Press S3 button, the minute digits will blink.
6. Press S1 button once to increase the digits by one unit, holding down the button will speed up the process.
7. Press S3 button, the second digits will blink.
8. Press S1 button to reset the second digits to zero.
9. Follow the same pattern to set month, date, day

(of the week), hour format and calendar format.

10. To set the hour format, press S1 button to toggle between 12-hour and 24-hour format. The PM indicator may display to indicate the time in 12-hour format.
11. To set the calendar format, press S1 button to toggle between M-D (month-date) and D-M (date of month) format.
12. When finished making all the settings, press S2 button to confirm.

NOTE: The chosen hour and calendar formats will apply to both home and foreign settings.

NOTE: In the FOREIGN TIME mode, only hour, minute, month, date, day (of the week) are opened to set.

ALARM

TO SET THE ALARM TIME

1. Press S3 button to select alarm mode.
2. Press S2 button to toggle between ALM1 and ALM2 mode.
3. Press and hold S2 button for 2 seconds until the "SET" message appears and the hour digits blink.
4. Press S1 button once to increase the digits by one unit. Holding down the button will speed up the process.
5. Press S3 button, the minute digits will blink.
6. Press S1 button to set the minute digits. Holding down the button will speed up the process.
7. When finished making all the settings, press S2 button to confirm.

TO TURN ON/OFF THE ALARM AND HOURLY CHIME

- In alarm mode,
1. Press S2 button to toggle between ALM1 and ALM2 mode.
 2. Press S1 button once to activate the daily alarm. Alarm indicator will appear.
 3. Press again to activate the hourly chime. Chime indicator will appear.
 4. Press the third time to activate both functions. Alarm indicator and chime indicator will appear.
 5. Press the fourth time to deactivate both functions. Alarm indicator and chime indicator will disappear.

WHEN AN ALARM OR HOURLY CHIME GOES OFF

A tune will go off by the hour if the hourly chime function is activated.

A 20-second alarm tune will be emitted at the designated time when the alarm is activated. To stop the tune, press any button.

To disable the functions, press S3 button to select ALM1 or ALM2 mode, then press S1 button to turn off the indicator of the function as desired.

STOPWATCH

TO USE THE STOPWATCH

1. Press S3 button to select STOPWATCH mode.
2. The stopwatch will be displayed in its current state - stopped, running or reset.
3. To resume a stopped counting, press S1 button to resume from where it left off.
4. To start a new counting, reset the stopwatch to zero first. Press S1 button to stop counting and then press and hold S2 button for approximately 3 seconds to reset the counter to zero.

For the measurement of elapsed time:
In STOPWATCH mode,

1. Press S1 button to start counting.
2. To stop counting, press S1 button once. Press S1 button again to resume from where it left off.
3. To reset to zero, press S1 button to stop counting and then press and hold S2 button for approximately 3 seconds.

For the measurement of lap time:
In STOPWATCH mode,

1. Press S1 button to start counting.
2. While the stopwatch is running, press S2 button once to register a lap. The lap number and lap time of the registered lap will be displayed. The

- stopwatch is still running in the background.
- After approximately 5 seconds, the lap number and the elapsed time of the current lap will be displayed.
3. Repeat the last step until all the laps have been registered.
 4. To reset to zero, press S1 button to stop counting and then press and hold S2 button for approximately 3 seconds.

NOTE: You can leave the stopwatch running while switching over to other operating modes. The stopwatch indicator will appear as a reminder.

NOTE: In the first hour of counting, the counted time will display in MM.SS.hh (minutes. seconds. hundredths). After 1 hour, the counted time will display in HH:MM.SS (hours: minutes. seconds).

NOTE: When the stopwatch has counted for more than 1 hour, once the counting is stopped, the counted time will be displayed in HH:MM.SS (hours: minutes. seconds) and MM.SS.hh (minutes. seconds. hundredths) at an alternate interval of 2 seconds.

NOTE: The stopwatch can record up to a maximum of 10 laps (first 10 laps).

NOTE: The stopwatch can count up to a maximum of 99 hours, 59 minutes and 59.99 seconds.

RECALL

TO USE THE RECALL MODE:

1. Press S3 button to select RECALL mode.
2. The total elapsed time [TTL] or the message "no DATA" (if there is no stored lap record) will be displayed.
3. Press S1 button to cycle the stored lap records in the order of total elapsed time [TTL], fastest lap time [FAST], slowest lap time [SLOW], average lap time [AVG] and individual lap record [LAP-XX].
4. When the individual lap record [LAP-XX] is displayed, press S2 button to cycle the stored individual lap records.

NOTE: In RECALL mode, the watch will automatically return to NORMAL TIME mode if there is no button pressed for 3 minutes.

NOTE: When the individual lap record [LAP-XX] is more than 1 hour, once the counting is stopped, the lap record will be displayed in HH:MM.SS (hours: minutes. seconds) and MM.SS.hh (minutes. seconds. hundredths) at an alternate interval of 2 seconds.

TIMER

TO SET THE TIMER

1. Press S3 button to select TIMER mode.
2. Press S2 button to alter the timer setting among 1, 3, 5, 10, 15, 25, 30, 45 and 60 minutes.

TO USE THE TIMER

- In TIMER mode,
1. Press S1 button to start counting.
 2. To stop counting, press S1 button once. Press S1 button again to resume from where it left off.
 3. To reset the timer, press S1 button to stop counting and then press and hold S2 button for approximately 2 seconds.
 4. After reaching zero in a countdown, a 20-second beep will be emitted. To stop the beeping, press any button, the timer will reload automatically.

NOTE: You can leave the timer running while switching over to other operating modes.

BACKLIGHT

TO USE THE BACKLIGHT

Press S4 button to turn on the backlight for approximately 3 seconds.

WATER RESISTANCE GUIDE

WATER RESISTANCE	SUITABLE ATMOSPHERE
3ATM / 30 METERS / 100 FEET / 30 METERS H2O	Suitable for washing hands and light splashing
5ATM / 50 METERS / 165 FEET / 50 METERS H2O	Suitable for light swimming. E.g.: Bathing in a pool or low tide waters, but not suitable for diving
10ATM / 100 METERS / 330 FEET / 100 METERS H2O	Suitable for most water sports. E.g.: Swimming, surfing and snorkeling, but not suitable for deep water diving
20ATM / 200 METERS / 660 FEET / 200 METERS H2O	Suitable for most water sports including deep water diving

WATER RESISTANCE GUIDE

may cause your watch to lose some of its water resistance.

6. Avoid exposing your watch to chemicals, soaps or solvents as they deteriorate the water resist seals in your watch.

7. Never try to remove the caseback, leave this to a certified watch repair technician or C9 service center. This will help in preventing water leakage from improper battery replacement.

8. It is advisable to have your watch pressure tested annually and to re-furbish your watch every 2-3 years to extend the life of the watch.

LIFETIME LIMITED WARRANTY

The Geneva Watch Group warranties that it will repair any failure due to defects in materials and/or workmanship free of charge. This warranty is by Geneva Watch Group, not by the dealer from whom it was purchased. This limited warranty does not cover replacement of crystal, battery, band, strap or case. Geneva Watch Group reserves the right to replace any or all inside components in lieu of repair. This warranty does not cover any failure to function properly due to misuse such as water immersion or severe shock. If your watch ever needs service, wrap it carefully in tissue paper or a similar soft material and pack it in a mailing carton. Send it via insured Parcel Post to: **47440 MICHIGAN AVE, SUITE 130 CANTON, MICHIGAN 48188, U.S.A.**, include a brief note explaining what is wrong. Be sure to print your name and address clearly. Enclose \$7.00 to cover the cost of return postage and handling. "Do not send cash or checks. Only money orders, Master Card or Visa are accepted."

Card Holder Name: _____

M.C. _____ Visa _____

Account Number: _____

Expiration Date: _____

USER GUIDE

FOLLOW THESE 8 TIPS TO GET THE MOST OUT OF YOUR NEW WATCH!

1. Never pull out the crown or operate the pushers/buttons under water.
2. Make sure your crown is returned to the original position before you expose your watch to water.
3. If your watch is exposed to saltwater, it is very important to wash it thoroughly under tap water and wipe dry with a soft cloth. Keep it clean!
4. Severe impacts or drops may affect your watches water resistance and performance.
5. Avoid exposing your C9 watch to extreme temperatures such as in a hot shower, Jacuzzi, sauna or hot tub. The combination of extreme heat and water